


## **Mini Peak II**

www.luxeoutdoor.com

Article # TL-5250



## SPECIFICATION

Outerfly: 68D Polyester Ripstop PU 1500mm 68D breathable Polyester + HD mesh Inner tent: Inner floor: 68D Polyester Taffeta PU 4000mm Pole: ( not included ) reflective rope 2.2mm dia x 2 lines

guyrope: stake 18cm alloy Y-stake x 8 pieces


Cord adjuster : glow in dark effect Weight: Outerfly +/-1000g Inner +/-500g alloy stake +/-120g

glue +/-35g

As the siliconed tents are designed without seam taping, we recommend users to apply seam sealing on inside seam of flysheet and certain points on inner tent corner in order to obtain better rainproof result if the tent will be subjected to prolonged rainfall or persistantly wet environment.

Seam Sealing the tent





## Assembly instruction

inner tent hanging system

18cm long

- Step 1 Lay the flysheet on the ground and form it into a square shape. Then stake 4 points on each corners to maintain the balance setting force.
- Step 2 assemble the hiking pole in 137-140cm. (not included) Then insert the hiking pole inside the flysheet and erect to set up the whole tent. - stake 2 side walls to enhance the setting,
  - put inner tent inside by hanging the S-hook on top.
  - 137-140cm Hiking pole

www.luxeoutdoor.com

