

# METEOR 2/3

## PITCHING INSTRUCTIONS




Congratulations on the purchase of your new Sierra Designs tent! In order to familiarize yourself with your new tent, we recommend you “test pitch” it before embarking on your wilderness adventure.

PACKAGE INCLUDES: Tent body, rain fly, 2 poles, guy cords, V-stakes, storage bag, and pole bag with stake pocket.

**STEP 1:** Find an even piece of ground; be sure the area is clear of debris. Lay out your tent as shown. Stake the 4 corners (circled).




**STEP 2:** Assemble the “X” pole. Locate the YELLOW pole ends and insert into tent corners with YELLOW SD Anchors/webbing.



**STEP 3:** Connect Tent Lite hooks to poles. Attached yellow ridge pole to Ball Cap Connectors.



**STEP 4:** Lay the rain fly over the tent body matching the RED corner of the tent with the RED corner on the fly.



**STEP 5:** On the UNDER side of the fly, Clip the SQ Rings to the Ball Cap Connector & wrap the 4 velcro loops to the tent poles. **NOTE:** this will ensure proper fly tensioning.



Attach fly cord loop around pole tip



Pull down String Lock cord to tighten



**STEP 6:** Attach fly cord loop around pole tip on all corners. Adjust tension by pulling down on String Lock cord. Stake out vestibules and your tent is fully set up!



# METEOR 2/3

## USING YOUR TENT




**GUYING OUT YOUR TENT:** Your tent includes guy out loops, guylines, and stakes. It is good practice to always guy out your tent, but is absolutely necessary when it's windy.

Tie the end of the guyline to the reflective guy out loop



Use the black LINE-LOK to adjust the length of the guy line.



Guy out your tent in the 4 locations shown below to prevent pole rotation/breakage during high winds.



**STARGAZER FLY:** The fly on your tent can be staked out and rolled in either of the two configurations shown below for stargazing enjoyment.



**FLY VENTING:** To increase ventilation in your tent, prop the vent in the "open" position.

